

## Mounting the tracker on an ULD.

Install the tracker on the inside of the ULD. Use rivets and washers to mount the tracker on the ULD. Recommended rivet dimensions D2: 12-14 mm is a good head diameter for 1101 IF (dome or flat head) D1: 5-6 mm is a good diameter for 1101 IF



Step 1

Install on the inside of the ULD. The area where to install is indicated with a green circle on the picture.



Step 2

Install the tracker in this area of the ULD.



Step 3

Indicate the mounting holes on the canvas with a pen or pencil.



Step 4

Drill both mounting holes through the canvas.



Step 5

Rivet the tracker with washers to secure good fastening. Top mounting hole first.



Step 6

Secure the complete mounting of the tracker by fastening the bottom with a second rivet and washer.



Step 7

The inside of the ULD with a mounted tracker looks like this.

Note: Use of our tracking solution with third-party shipping, courier, and logistics services might be subject to those providers' applicable terms and conditions. Users are responsible for reviewing and complying with all relevant third-party terms. Sensolus makes no representations regarding and assumes no liability for third-party terms or services, nor for any user non-compliance with third-party terms.