

Tracker installation

RTPs can come in a variety of shapes and sizes. This manual contains the general guidelines for the installation of trackers on RTPs. We use a fairly generic RTP form factor for this.

 <p>Make sure the tracker is not fully surrounded by metal parts, as this blocks the signal.</p>	 <p>Protect the tracker by using the cooler unit's shape if possible.</p>	 <p>Place the tracker as high as possible on the asset.</p>	 <p>Ensure the tracker has a clear view of the sky.</p>
---	--	--	--

Do's	Don'ts
Install the tracker as high as possible	On moving parts (lids, doors)
Vertical installation if possible	Close to forklift pick up holes
Clear view on the sky	Under the RTP (bad signal)
Use asset's cavities to install the tracker	On the very outside where the tracker might get hit by other equipment
Preferably use bolts and nuts to install the tracker	

