The TRACK 1101 and 1141 ship with a standard battery pack BAT 8206.

Please order these battery packs and replace with these battery packs. All info on the battery pack are on the documentation center.



Step 1

Make sure that the serial number and logo are facing the right way up. Then turn the tracker face down. Unscrew the 6 screws. Tip: If using a power drill, use power setting 7, on low. (Note: not all power drills have the same settings!)



**Step 2** Remove the back plate and the 6 screws.



**Step 3** Take the module (Battery pack + battery holder + PCB) out of the casing.

You might need to tilt the casing a bit



**Step 4** Turn around the module (Battery pack + battery holder + PCB) so the PCB is on top.



**Step 5** Lift the module and move the battery pack from the insert to the side.



**Step 6** Align the battery pack next to the PCB and insert.



**Step 7** Disconnect the battery pack from the PCB. Be carefull in disconnecting the battery pack.



**Step 8** Connect the new the battery pack to the PCB. A green LED will flash for some seconds.



**Step 9** Move the battery pack back under the insert and PCB and flip the module.



**Step 10** Align the battery pack onto the insert.



**Step 11** Place the module in the tracker. Use the alignment marks on the casing. Do not use force. There is only one way to put the module back in the tracker.



**Step 12** Close the tracker carefully. Your tracker is ready to use again.

## Indicate battery replaced in platform

SYSTEM		Search	۹ 🖸	③ ₽ 🏵
← 📦 Container 1234				View
Tracker info Configuration Subscripti	Diagnostic			More ~
Battery status	_			
19%	Status Battery is estimated to last till Januar Battery consumption started on 22 ja Intended battery life is set to <b>7 years</b> Replace battery Mark empty   Rese	anuary 2022 s (at least till 2 Feb 2029).		
Replace battery				O Sear X
Do you want to replace the	battery? It will reset all batte	ery information.		Sé

When you replaced the battery in the tracker you have to indicate thet in the platform.

- Go to the tracker details page in the general section. You can search for this tracker or find in in the asset list or asset map.
- Click ont the settings button on the far right
- Go to the battery tab
- Click replace battery

Cancel

Replace